

**MANCHONS PREISOLES POUR CABLES DE RESEAU AERIEN BT  
ISOLES TORSADES**

NF C 33-021

RECOMMANDATIONS POUR LA MISE EN OEUVRE

**PREPARATION DU CONDUCTEUR A RACCORDER :**

- Couper le conducteur avec un dispositif qui n'écrase pas l'âme.
- Dénuder le conducteur sur la longueur indiquée sur le manchon.
- Brosser le conducteur à raccorder sous graisse neutre. Ne pas essuyer le conducteur ainsi nettoyé.
- Introduire le conducteur à fond dans l'alésage du manchon.

**RETREINTS :**

- Utiliser une presse adaptée dotée de la matrice hexagonale préconisée.
- Réaliser les rétreints dans la zone marquée à cet effet en suivant l'ordre des numéros.
- 3 rétreints de 9mm de largeur d'empreinte de chaque coté du manchon.



**PREINSULATED SLEEVES FOR LOW VOLTAGE AERIAL BUNDLED CONDUCTORS**

ADVICES FOR IMPLEMENTATION

**PREPARATION OF THE CONDUCTOR TO CONNECT :**

- Cut the conductor with a device that does not scratch the core.
- Strip the conductor over the length indicated on the sleeve.
- Brush the conductor to connect with neutral grease. Do not dry the conductor cleaned this way.
- Insert the conductor fully in the sleeve bore.

**CRIMPING :**

- Use a press fitted with the advised hexagonal crimping die.
- Crimp in the indicated area in the order of the numbers.
- 3 crimps of 9mm width on each side of the sleeve.



16.06

**MICHAUD**

**10 MANCHONS PREISOLES POUR CABLES DE RESEAU AERIEN BT  
10 PREINSULATED SLEEVES FOR LOW VOLTAGE ABC :**

NF C 33-021

CODE	DESIGNATION	CODET
K101	MJPT 16	
K103	MJPT 25	
K106	MJPT 35	67 22 652
K108	MJPT 50-25	67 22 653
K109	MJPT 50-35	67 22 654
K110	MJPT 50	67 22 655

CODE	DESIGNATION	CODET
K114	MJPT 54-50	
K118	MJPT 70-35	67 22 656
K119	MJPT 70-50	67 22 657
K121	MJPT 70	67 22 658
K122	MJPT 95-70	67 22 659
K123	MJPT 95	67 22 660